

- support midp2.0 java for mobile phones, PDA and other mobile devices.
- Chinese and English interface is adaptive.
- Copy “Mobile Player.jar” to the memory device and install it.
- Run “ipcamera player”.
- Set alias, hostname or IP (The IP be set must be accessed through the Internet. of course, if your mobile device access the LAN with wifi, then the IP is just the LAN IP), port, user, pwd, resolution (160 * 120, only the new version of the camera supports)
- Click OK to see the camera picture
- 2 4 6 8 keys can control the camera movement up and down about with the image display direction.
- 1 3 7 9 keys can control the camera started to cruise around, stop, vertical cruise started, stop.
- Open menu and then click the list of ip camera in the LAN to search camera which you will view(only in the LAN through the wifi situation).
- Esmertec Jbed 20090217.5.1R2 is a batch for windows mobile system.